



Precision Vacuum Planters

7" x 7" Mounted



Operator & Parts Manual

Includes Instructions for:

- **Safety**
- **Operation**
- **Maintenance**

INTRODUCTION

Congratulations on your purchase of a MONOSEM planter.

This manual has been prepared for use in operation, adjustment, and maintenance of the planter. Read this manual carefully before operating your planter.

The information used in compiling this manual is current, however as production changes do occur on a continual basis, Monosem Inc. reserves the right to change specifications or designs without notice and without the obligation to install the same on previously manufactured machines.


Please take the time now to record your serial number and date of purchase for a reference when ordering replacement parts for your Monosem NG Plus 4 planter.

Serial Number _____

Date _____

The WARRANTY for your NG Plus 4 planter is printed on the back cover.



While reading your manual you will see the symbol  and the words **CAUTION, WARNING, DANGER**. Pay particular attention to the safety information given. Failure to observe the safety symbols can cause damage to the machine and/or personal injury. A detailed description of the safety symbols and their meaning is found in the safety section of this manual.

2 precautions for successful planting:

1. Choose a reasonable working speed adapted to the field conditions and desired accuracy.
2. Check proper working of the seed metering, seed placement, spacing and density when starting up and from time to time during planting.

... and don't forget – accurate planting is the key to a good stand!

QUICK REFERENCE

7" x 7" 3pt MOUNTED

SAFETY	1
GENERAL SAFETY	1. 1
BEFORE OPERATION	1. 1
DURING & FOLOWING OPERATION	1. 2
UNHOOKING THE PLANTER	1. 2
STORING THE PLANTER	1. 2
PERFORMING MAINTENANCE	1. 3
TIRE SAFETY	1. 3
DRIVE LINE SAFETY	1. 3
HYDRAULIC SAFETY	1. 3
SAFETY STICKERS	1. 4

PREPARING THE PLANTER	2
LUBRICATION	2. 1
CHAIN TENSION ADJUSTMENT	2. 2
TIRE PRESSURE	2. 2
VALVE BLOCK INSPECTION	2. 2
TRACTOR HOOKUP	2. 3
LEVELING THE PLANTER	2. 4
TRANSPORTING THE PLANTER	2. 4
OPERATING SPEED	2. 4
FIELD TEST	2. 4
CHECKING SEED POPULATION	2. 5
UNHOOKING THE PLANTER	2. 5
STORING THE PLANTER	2. 5

FRAME	3
ASSEMBLY - 7 X 7 FRAME	3.1
ASSEMBLY - REAR WHEEL BLOCK	3.3
ASSEMBLY - FRONT WHEEL BLOCK	3.5

TRANSMISSION	4
PLANTING RATE CHART	4.1
ASSEMBLY - SINGLE PLATE TRANS.	4.2
ASSEMBLY & ADJ. TRANSMISSION	4.2
SEED POPULATION CHART	4.3

DRIVE	5
STANDARD TURBOFAN	5.1
ASSEMBLY-STANDARD TURBOFAN	5.2
ASSY - HIGH OUTPUT TURBOFAN	5.4-5.5
ASSY - EXTRA HIGH OUTPUT	5.6-5.7
ASSEMBLY - HYDRAULIC DRIVE	5.8-5.9
VACUUM GAUGE SETTINGS	5.10
ASSEMBLY - VACUUM GAUGE	5.10

ROW UNIT	6
SEED DEPTH	6.1
V PRESS WHEELS	6.1
DEPTH GAUGE WHEELS	6.2
DOUBLE DISC OPENERS	6.2
STABILIZER SPRINGS	6.2
DRIVE CHAIN	6.2
SEED HOPPER	6.2
SEED METERING SYSTEM	6.3
EXTRA LARGE SEED	6.4
DISENGAGING THE METER BOX	6.4
SEED TUBE	6.4
METERING BOX ADJUSTMENT	6.5
SEED DISC	6.5
SEED CHUTE	6.5
SEED DISC IDENTIFICATION	6.6
SEED DISC RECOMMENDATIONS	6.6
ASSEMBLY - ROW UNIT	6.8
ASSEMBLY-CLOSING WHEEL	6.10
ASSEMBLY-GAUGE WHEEL ARM	6.10
ASSEMBLY-GAUGE WHEEL	6.11
ASSEMBLY-METERING BOX	6.12
METERING BOX TROUBLESHOOTING	6.13
ASSY-UP/ DOWN PRESSURE SPRING	6.14
ASSEMBLY - HILLER DISCS	6.16
ASSEMBLY - CONCAVE PRESS WHEEL	6.18

OPTIONAL EQUIPMENT	7
ATTACHMENTS	7.0
ROW MARKERS	7.1
AIR INSECTICIDE SYSTEM	7.2
US GRANULAR INSECTICIDE SYSTEM	7.3
MICROSEM MICROGRANULAR SYSTEM	7.4
DRY FERTILIZER	7.5
LIQUID FERTILIZER	7.7

SPECIFICATIONS

7" x 7" 3pt MOUNTED

FRAME : Three Point Mounted
 Double Rigid Toolbar:
 7"x7" Bottom Toolbar
 5"x5" Top Toolbar

PLANTING UNIT : NG Plus 4 Monosem
 Vacuum Metering Box
 Double Disc Opener
 Gauge Wheels
 Adjustable Closing Wheels

STANDARD ROW SPACING	WIDTH	WEIGHT*
4-Row 30	12'	2080 lbs.
4-Row 36-40"	14'	2160 lbs.
6-Row Narrow – 30" Rows	15'	2709 lbs.
6-Row Wide – 36-40" Rows	20'	2954 lbs.
8-Row Narrow – 30" Rows	20'	3476 lbs.
8-Row Wide – 36-40" Rows	25'	4180 lbs.
12-Row Narrow – 22-24" Rows (sugarbeets)	23'	4940 lbs.

*The base machine weights include planter frame, drive components, tires and wheels, hydraulic cylinders and NG Plus 4 row units with seed hopper and lid.

DRIVE SYSTEM

Ground Drive, 7.60x15" 6-Ply Tires
 Two Drive/Gauge Wheels on 6-Row,
 8-Row and 12-Row Narrow

TRANSMISSION

End Mounted, Quick Adjusting Sprockets
 One on 6-Row Models
 Two on 8 & 12-Row Models

MARKERS

Low Profile Single and Double Fold

TURBOFAN

540, 450 or 1000 rpm
 500 rpm High Output
 540 Extra High Output

OPTIONAL EQUIPMENT

Hydraulic Driven Turbofan
 Electronic Seed Monitor
 Microsem Insecticide System
 Disc Hiller System, w/Flat or V Press Wheel
 Lift Assist Wheels
 U.S. Insecticide
 U.S. Insecticide/Herbicide
 No-Till & Minimum Till Attachments
 Row Markers